



Pretreatment User Guide

APPLICATION AND USE INSTRUCTIONS

Before Use:

- 1 Always test pretreatment prior to any production run. Residual chemicals from the manufacturing process or poor dye selections can cause adverse reactions to pretreatment, including discoloration.
- 2 You **DO NOT** need to dilute or mix SonicJet Pretreat Solution. Simply shake the container and it will be ready to use (RTU).
- 3 When returning unused pretreatment from a machine to the container, strain it to ensure no fibers, dirt, dust or other contaminants are in the solution.

Application:

- 1 When applying pretreatment to the garment, make sure to apply it as evenly as possible. Automatic pretreatment machines are recommended.
- 2 Always store pretreated garments out of direct sunlight.
- 3 When returning unused pretreatment from a machine to the container, strain it to ensure no fibers, dirt, dust or other contaminants are in the solution.
- 4 The amount of pretreatment liquid you will need to apply will vary depending on the size, weight and darkness of your garment. Larger, heavier and/or darker garments will require more liquid.
- 5 A good starting point is 16-22 grams per 14"x14" area.
- 6 **NOTE:** 18-26 grams may provide you with better washability and white optical brightness.
- 7 Always use a high-quality garment that is ring-spun with a tightly knit weave. The smoother and tighter the weave, the better your final DTG print.