

End Of Day Maintenance

REVEL DTF
2402T / 1202T



Table of Contents

1. Undock Print-Head

2. Maintenance Station

- a. Clean Ink-Caps
- b. Clean Wiper
- c. Moisturize Ink-Caps

3. Check/Clean Print-Head Nozzles

4. Dock Print-Head




Step 1: Undock Print-Head

- Press and hold the “Left Arrow” button on the printer panel or on PrintEXP to move the print-head to the left side of the printer.




Step 2: Maintenance Station

1. Ink Cap 1 (Color Ink Cap)
2. Ink Cap 2 (White Ink Cap)
3. Wiper




Step 2a: Clean Ink-Caps

- Using a foam applicator and cleaning solution, clean the outer edges of the Ink-Caps.




Step 2b: Clean Wiper

- Using a lint-free wipe and cleaning solution, clean the blue wiper located to the left of the ink-caps.



Step 2c: Moisturize Ink-Caps

- Pour moisturizing fluid directly into the Ink-Caps, filling them to just under capacity.



Step 3: Check/Clean Print- Head Nozzles

- Pull down the “Mirror Drawer” on the left side of the printer.
- Use the mirror to check the bottom of the print-head. Using a lint-free wipe and cleaning solution, clean any dried ink collecting around the Print-Head Nozzles.
- **Do not wipe directly on the metal Print-Head Nozzles.**



Step 4: Dock Print-Head

- Press the “Enter” button on the printer panel or the “X Reset” button on PrintEXP to move the print-head back to the Maintenance Station on the right side of the printer.

